
PROBAR
BAR PRODUCTS


GLASS WASHER · HOW TO USE

Washing glasses in the sink, in 5 steps

The glass washer sits in the sink and runs on cold water, from the mains or from a tank. It brushes the glass inside and out, then rinses it with clean water.




1



Position

Place the glass washer in the sink. Four suction cups hold it in place.


2



Connect

Connect the hose (3/8", 70 cm) to the tap or, with no water supply, to the pump of a water pump kit. Waste water drains into the sink.


3



Brush

Place the glass upside down on the brushes and turn it. The brushes clean inside and out at the same time.


4



Rinse

Place the glass upside down on the nozzle. Clean water rinses it inside and out.

5



Drain

Stand the glass on the drip mat. It is ready for service straight away.

SPECIFICATIONS

- **Glasses Ø 50 to 140 mm**, up to 240 mm tall
- **37 x 20 cm**, 36 cm high
- **Cold water**, below 30 °C
- **3/8" hose**, 70 cm, included
- **Removable centre brush**, for cleaning

Questions about setting up? We are happy to help.

Message us on WhatsApp